

## Parts List — SR5017

| Part Number | Description                                             | Config Step                 | Qty |
|-------------|---------------------------------------------------------|-----------------------------|-----|
| 250876      | MANUAL, OPERATORS                                       | Configuration Type          | 1   |
| 417000      | BDL, SINGLE RANK SR6015                                 | Tank Configuration          | 1   |
| 270225      | SCALE, DIGITAL - HANDHELD                               | Tank Configuration          | 1   |
| 419095-1    | BDL, RESIDUE WHEEL - SPLIT BUSHI 6015 SR - STAGE 3      | Tank Configuration          | 1   |
| 419096      | BDL, OPENER HOSE HOLDERS SB - SR                        | Tank Configuration          | 1   |
| 400532      | BDL, HD FERT KNIFE - SR                                 | Tank Configuration          | 1   |
| 419093      | BDL, OPENERS - SR6015 - INLINE                          | Opener Configuration        | 1   |
| 400678      | BDL, SEED KNIFE IL OFFSET RIGHT - SR                    | Opener Configuration        | 48  |
| 400679      | BDL, SEED KNIFE PAIRED ROW - SR                         | Opener Configuration        | 48  |
| 270132      | KIT, IN-CAB - VIPER 4+ - No GPS                         | Raven Monitor               | 1   |
| 270155      | CODE, UNLOCK VIPER 4 COMBO VRA (SINGLE+MULTI)           | VRA Unlock Code             | 1   |
| 451144-1    | BDL, SEEDBDL, SEEDMASTER, REMOTE TANK MONITOR - STAGE 2 | Remote Tank Monitor         | 1   |
| 417056-1    | CTN, HYD - FRONT HITCH EXTENSION KIT - SR15             | Front Hitch Hose Extensions | 1   |
| 419400      | BDL, HITCH - REAR - SR15 - STAGE 1                      | Rear Hitch Option           | 1   |